



- 1. Tripod Collar
- 2. A-M Index
- 3. A-M Ring
- 4. Lens Barrel
- 5. Focus Ring
- 6. Distance Scale Window
- 7. Aperture Index/
Mounting Index *
- 8. Focusing Limit Switch

- 9. A-M Button
- 10. Aperture Ring
- 11. Minimum Aperture Signal Post
(EE Servo Coupling Post)
- 12. AF Couplings
- 13. Minimum Aperture Lock Lever
- 14. Aperture Scale
- 15. ADR (Aperture Direct Readout) Scale
- 16. Aperture Indexing Post
- 17. CPU Contacts

- 18. Meter Coupling Ridge
- 19. Tripod Collar Alignment Index
- 20. Tripod Collar Lock Screw
- 21. Reproduction Ratio Scale
- 22. Distance scale
- 23. Depth of field Indicator
- 24. Distance Index

* You can also use a black screw on the lens bayonet as the mounting index.